



PoE Giga-MiniMc and PoE+ Giga-MiniMc

Operation Manual



Above illustration is representative; some minor differences may be present in actual product.

FCC Radio Frequency Interference Statement

This equipment has been tested and found to comply with the limits for a Class A computing device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which the user will be required to correct the interference at his own expense.

Any changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

The use of non-shielded I/O cables may not guarantee compliance with FCC RFI limits. This digital apparatus does not exceed the Class A limits for radio noise emission from digital apparatus set out in the Radio Interference Regulation of the Canadian Department of Communications.

Le présent appareil numérique n'émet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de classe A prescrites dans le Règlement sur le brouillage radioélectrique publié par le ministère des Communications du Canada.

Warranty

IMC Networks warrants to the original end-user purchaser that this product, EXCLUSIVE OF SOFTWARE, shall be free from defects in materials and workmanship under normal and proper use in accordance with IMC Networks' instructions and directions for a period of six (6) years after the original date of purchase. IMC Networks warrants to the original end-user purchaser that all SFPs shall be free from defects in materials and workmanship under normal and proper use in accordance with IMC Networks' instructions and directions for a period of one (1) year after the original date of purchase. This warranty is subject to the limitations set forth below.

At its option, IMC Networks will repair or replace at no charge the product which proves to be defective within such warranty period. This limited warranty shall not apply if the IMC Networks product has been damaged by unreasonable use, accident, negligence, service or modification by anyone other than an authorized IMC Networks Service Technician or by any other causes unrelated to defective materials or workmanship. Any replaced or repaired products or parts carry a ninety (90) day warranty or the remainder of the initial warranty period, whichever is longer.

To receive in-warranty service, the defective product must be received at IMC Networks no later than the end of the warranty period. The product must be accompanied by proof of purchase, satisfactory to IMC Networks, denoting product serial number and purchase date, a written description of the defect and a Return Merchandise Authorization (RMA) number issued by IMC Networks. No products will be accepted by IMC Networks which do not have an RMA number. For an RMA number, contact IMC Networks at PHONE: (800) 624-1070 (in the U.S and Canada) or (949) 465-3000 or FAX: (949) 465-3020. The end-user shall return the defective product to IMC Networks, freight, customs and handling charges prepaid. End-user agrees to accept all liability for loss of or damages to the returned product during shipment. IMC Networks shall repair or replace the returned product, at its option, and return the repaired or new product to the end-user, freight prepaid, via method to be determined by IMC Networks. IMC Networks shall not be liable for any costs of procurement of substitute goods, loss of profits, or any incidental, consequential, and/or special damages of any kind resulting from a breach of any applicable express or implied warranty, breach of any obligation arising from breach of warranty, or otherwise with respect to the manufacture and sale of any IMC Networks product, whether or not IMC Networks has been advised of the possibility of such loss or damage.

EXCEPT FOR THE EXPRESS WARRANTY SET FORTH ABOVE, IMC NETWORKS MAKES NO OTHER WARRANTIES, WHETHER EXPRESS OR IMPLIED, WITH RESPECT TO THIS IMC NETWORKS PRODUCT, INCLUDING WITHOUT LIMITATION ANY SOFTWARE ASSOCIATED OR INCLUDED. IMC NETWORKS SHALL DISREGARD AND NOT BE BOUND BY ANY REPRESENTATIONS OR WARRANTIES MADE BY ANY OTHER PERSON, INCLUDING EMPLOYEES, DISTRIBUTORS, RESELLERS OR DEALERS OF IMC NETWORKS, WHICH ARE INCONSISTENT WITH THE WARRANTY SET FORTH ABOVE. ALL IMPLIED WARRANTIES INCLUDING THOSE OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY LIMITED TO THE DURATION OF THE EXPRESS WARRANTY STATED ABOVE.

Every reasonable effort has been made to ensure that IMC Networks product manuals and promotional materials accurately describe IMC Networks product specifications and capabilities at the time of publication. However, because of ongoing improvements and updating of IMC Networks products, IMC Networks cannot guarantee the accuracy of printed materials after the date of publication and disclaims liability for changes, errors or omissions.

Table of Contents

FCC Radio Frequency Interference Statement	ii
Warranty.....	ii
About the PoE Giga-MiniMc.....	1
Installation	1
DIP Switch Configuration SFP and 1x9	2
LED Operation SFP and 1x9.....	4
Powering Option.....	6
DIN Rail and Wallmount Bracket	6
DC Power Supply Precautions.....	8
Troubleshooting.....	8
RJ-45 Pinouts	8
Specifications for the PoE Giga-MiniMc.....	10
Notes.....	12
About the PoE+ Giga-MiniMc.....	13
Installation	13
DIP Switch Configuration SFP and 1x9	14
LED Operation SFP and 1x9.....	16
Powering Options	18
DIN Rail and Wallmount Bracket	19
DC Power Supply Precautions.....	20
Troubleshooting.....	20
RJ-45 Pinouts	21
Specifications for the PoE+ Giga-MiniMc.....	22
Notes.....	24
PoE Precautions (For Inside-a-Building Installation ONLY)	25
IMC Networks Technical Support.....	26
Fiber Optic Cleaning Guidelines.....	27
Electrostatic Discharge Precautions.....	27
Safety Certifications.....	28

About the PoE Giga-MiniMc

The PoE Giga-MiniMc is a solution for private network applications that require power over Ethernet and locations inside buildings where PoE is required to power a unit. The standalone unit has one SFP uplink for the network connection, one PSE 10/100/1000Base-T copper port that provide Power-over-Ethernet (IEEE802.3af) and one copper port. These are intended to power local customer devices at the end of the fiber Line. The PoE Giga-MiniMc provisions up to 15.4 watts on one copper port, and can be powered by an external AC adapter or DC terminal block. For more robust power requirements on both copper ports, please refer to the information about the PoE+ Giga-MiniMc on Page 13.

The SFP uplink can support fiber or copper SFPs. The fiber SFP, available in SC or LC connectors, supports 100FDX or 1000FDX; a copper SFP supports the SGMII interface (10/100/1000Mbps). The SFP, with or without DDMI, is available for purchase through IMC Networks Distributors. The SFP must be MSA-compliant.

The copper ports Auto Negotiate to the connected device's speed and duplex mode: 10 Mbps, 100 Mbps or 1000 Mbps, and HDX or FDX (including Flow Control). The PoE Giga-MiniMc supports jumbo frames up to 10240.

Installation


PoE Giga-MiniMc installs virtually anywhere: as a standalone, table-top device, on a DIN rail, or using a Wallmount bracket. As a standalone device, the end user can install PoE Giga-MiniMc in locations with extremely limited space. Velcro strips are also included to attach the device to most surfaces. The DIN Rail clips and Wallmount bracket are optional, available for purchase.

Installation Tip

Several models of the PoE Giga-MiniMc support single-strand fiber for operation. Since single-strand fiber products use optics that transmit and receive on two different wavelengths, single-strand fiber products must be deployed in pairs. For example, connect a PoE Giga-MiniMc , TX/SSLX-SM1310-SC (which has 1310 xmt and 1550 rcv) to a product which has 1550 xmt and 1310 rcv, e.g. iMcV-Gigabit, TX/SSLX-SM1550-SC. The two connected products must also have the same speed and distance capabilities (i.e. both are single-mode [20km] or both are single/PLUS [40km]).

DIP Switch Configuration SFP and 1x9

PoE Giga-MiniMc SFP



DIP Switch	Name	Description	Default Setting
1	PoE Reset	ON forces Port 2, PSE/PoE, to OFF on LOS of Fiber input	OFF
2	Factory Set	Do not change	OFF
3	LoSpd	ON sets SFP for low speed operation	OFF
4	Factory Set	Do not change	OFF
5	Factory Set	Do not change	OFF
6	Factory Set	Do not change	OFF

LoSPd DSW for PoE Giga-MiniMc

The DIP Switch for LoSPd is to allow the end user to set a speed for a fiber SFP under the following conditions:

- Setting the LoSPd DSW to ON will force the SFP to operate at 100Mbps. When set in the default of OFF, the SFP will run at its maximum rate of the SFP installed.
- If a dual speed fiber SFP 100/1000Mbps is installed, setting the LoSpd to ON will force the SFP to operate at 100Mbps.


NOTE

Under no conditions will the LoSPd DSW impact any copper SFPs. Some 1000Mbps SFPs may not function properly when forced to 100Mbps.

PoE Reset DSW

When set to ON, it will force the PSE output power on the copper port OFF when the LINK state is lost on the SFP line (copper or fiber SFP). By default, the DSW is set to OFF.

PoE Gig-MiniMc 1x9



DIP Switch	Name	Description	Default Setting
1	PoE Reset	ON forces Port 2, PSE/PoE, to OFF on LOS of Fiber input	OFF
2	Factory Set	Do not change	OFF
3	Factory Set	Do not change	OFF
4	Factory Set	Do not change	OFF
5	Factory Set	Do not change	OFF
6	Factory Set	Do not change	OFF


PoE Reset DSW

When set to ON, it will force the PSE output power on the copper port OFF when the LINK state is lost on the fiber segment. By default, the DSW is set to OFF.

LED Operation SFP and 1x9

The PoE Giga-MiniMc includes LEDs for three ports, as shown below:

PoE Giga-MiniMc SFP




SFP LED Functions are as follows:

FLT	Glows red when a fault has been detected on the unit
LNK	Glows green with a valid link
1000 Mbps	Glows green when SFP is running at 1000Mbps
PWR	Glows green when unit is powered

RJ-45 LED Functions are as follows:

LNK/ACT	Glows green with a valid link Blinks green when activity is detected
PSE	Glows green when port is supplying PoE power Blinks green during training and fault conditions: a series of two flashes indicates an overcurrent fault; a series of five flashes indicates invalid low or high discovery signature resistance Off if the port is not supplying power
FDX	Glows amber when port is running full duplex

PoE Giga-MiniMc 1x9



1x9 LED Functions are as follows:

FLT	Glows red when a fault has been detected on the unit
LNK	Glows green with a valid link
1000 Mbps	Glows green when is running at 1000Mbps
PWR	Glows green when unit is powered

RJ-45 LED Functions are as follows:

LNK/ACT	Glows green with a valid link Blinks green when activity is detected
PSE	Glows green when port is supplying PoE power Blinks green during training and fault conditions: a series of two flashes indicates an overcurrent fault; a series of five flashes indicates invalid low or high discovery signature resistance Off if the port is not supplying power
FDX	Glows amber when port is running full duplex

NOTE

The fixed twisted pair port labeled PSE is the only port capable of providing Power Over Ethernet.

Powering Option


As a standalone unit, the PoE Giga-MiniMc uses a universal external desktop switching power adapter. The PoE Giga-MiniMc also includes a DC terminal block to support a voltage range of 45 to 57 VDC

PoE Giga-MiniMc supports two powering options.

- Desktop AC power adapter with country specific power cord (included)
- The 4-terminal DC power block

DC Terminal Block Wiring Instructions

The PoE Giga-MiniMc can be powered via the DC terminal block. From a power source, connect to any one positive and any one negative terminal on PoE Giga-MiniMc.



PoE Giga-MiniMc

NOTE


When using stranded wire, the leads must be tinned, and equivalent to a 16 AWG solid conductor. The *PoE Giga-MiniMc* is protected against mis-wiring; if mis-wired the *PoE Giga-MiniMc* will not function. The *PoE Giga-MiniMc* cannot support -48 VDC.

DIN Rail and Wallmount Bracket

The PoE Giga-MiniMc can be mounted with DIN Rail clips, a hardware option available through IMC Networks. The DIN Rail clips include screws, to allow the installation onto a DIN Rail. Install the screws into DIN Rail clips, which should be mounted perpendicular to the DIN Rail. Snap the converter onto the clips. To remove the converter from the DIN Rail, use a flat-head screwdriver into the slot to gently pry the converter from the rail. In addition, a Wallmount bracket can be installed onto the PoE Giga-MiniMc.

NOTE

The DIN clips are designed for use on a DIN-35 rail.



Wallmount Bracket

Din Rail Mounting

NOTE

The DIN clips are designed for use on a DIN-35 rail.

When using the side-installed location, remove the countersunk screw from the enclosure, and then use the vacated hole for one of the DIN clip screws.

DC Power Supply Precautions


The following precautions should be observed when installing chassis with DC power supplies.

1. Check nameplate ratings to assure there is no overloading of supply circuits that could have an effect on overcurrent protection and supply wiring.
2. When installing 45 to 57 VDC rated equipment, it must be installed only per the following conditions:
 - a. Connect the equipment to a 45 to 57 VDC supply source that is electrically isolated from the alternating current source. The 45 to 57 VDC source must be connected to a 45 to 57 VDC SELV source.
 - b. The maximum terminal voltage is 57 VDC.
 - c. Input wiring to terminal block must be routed and secured in such a manner that it is protected from damage and stress. Do not route wiring past sharp edges or moving parts.
 - d. A readily accessible disconnect device, with a 3mm minimum contact gap, shall be incorporated in the fixed wiring.
3. Grounding: reliable grounding of this equipment must be maintained. Particular attention should be given to supply connections when connecting to power strips, rather than direct connections to the branch circuit. The Negative Terminal is common to the grounded case.
4. -48 VDC cannot be supported.

Troubleshooting

- PWR LED glows green when the unit is powered. If this LED is not lit, contact IMC Networks Technical Support.
- If the PSE LED flashes twice, it may indicate an over current condition. The PSE LED should maintain solid green, to indicate consistent power. Check the PD device and its requirements.

The following table lists the pin configuration for the RJ-48 connector.



Pin#	Signal Name 1000M	Signal Direction 10/100M	PoE PoE+ (ALT-B)
1	TXD1+	Out*	
2	TXD1-	Out*	
3	RXD2+	IN*	
4	D3+		+V
5	D3-		+V
6	RXD2-	In*	
7	D4+		-V
8	D4-		-V

Specifications for the PoE Giga-MiniMc

Multi-mode 1300nm Dual Fiber
Single-mode 1310nm 1550nm Dual Fiber
Single-mode 1310nm 1490nm Single-Strand Fiber
Single-mode 1310nm 1550nm Single-Strand Fiber
Copper 10/100/1000Mbps

Ethernet Connections

10/100/1000 BaseT
Auto Negotiation
AutoCross
Flow Control
10240 MTU
Full Line-Rate Forwarding

DC Input Voltage

45 VDC to 57 VDC on DC terminal block
48 VDC on DC jack

AC Desktop Adapter

100 to 240 \pm 10% VAC input, 48 VDC output, 0.62A max

Power Consumption

21W max (PSE + PD)
5W max (PSE)

Operating Temperature

+32°F to +143.6°F (0°C to +62°C) DC terminal block
+32°F to +122°F (0°C to +50°C) with IMC supplied AC desktop adapter

Storage Temperature

-40°F to +185°F (-40°C to +85°C)

Humidity

5% to 95% (non-condensing); 0 to 10,000 ft. altitude

Power Characteristics

Consumes less than 10 watts (heating) plus PSE power
IEEE802.3af Power to field < 15.5 watts Powered from external 48 VDC power jack
Powered from external 45 to 57 VDC 4-position terminal block
The input power terminals are isolated from the unit chassis
Threaded Chassis Grounding holes on unit for ground lug mounting

Standards Compliance

IEEE 802.3af Power Over Ethernet

IEEE 802.3 Ethernet Standards

IEEE 802.3u Auto-Negotiation

RFC-2474

RFC-2475 DiffServ QoS

IMC Networks Products	Length of Warranty
SFPs	1 year
PoE Giga-MiniMc	6 year

NOTE

Please refer to the Warranty Section at the beginning of this manual for the full terms of the warranty.

Notes

About the PoE+ Giga-MiniMc

The PoE+ Giga-MiniMc is a solution for private network applications that require power over Ethernet and locations inside buildings where PoE is required to power a unit. The standalone unit has one SFP uplink for the network connection and two PSE 10/100/1000Base-T copper ports that provide Power-over-Ethernet (IEEE802.3af/at). These are intended to power local customer devices at the end of the fiber Line. The PoE+ Giga-MiniMc provides up to 25.4 watts per copper port and is powered by an external AC adapter or DC terminal block.

The SFP uplink can support fiber or copper SFPs. The fiber SFP, available in SC or LC connectors, supports 100FDX or 1000FDX; a copper SFP supports the SGMII interface (10/100/1000Mbps). The SFP, with or without DDMI, is available for purchase through IMC Networks Distributors. The SFP must be MSA-compliant.

The copper ports Auto Negotiate to the connected device's speed and duplex mode: 10 Mbps, 100 Mbps or 1000 Mbps, and HDX or FDX (including Flow Control). The PoE+ Giga-MiniMc supports jumbo frames up to 10240.

Installation


PoE+ Giga-MiniMc installs virtually anywhere: as a standalone, table-top device, on a DIN rail or using a Wallmount bracket. As a standalone device, the end user can install PoE+ Giga-MiniMc in locations with extremely limited space. Velcro strips are also included to attach the device to most surfaces. The DIN Rail clips and Wallmount bracket are optional, available for purchase.

Installation Tip

Several models of the PoE+ Giga-MiniMc support single-strand fiber for operation. Since single-strand fiber products use optics that transmit and receive on two different wavelengths, single-strand fiber products must be deployed in pairs. For example, connect a PoE+ Giga-MiniMc, TX/SSLX-SM1310-SC (which has 1310 xmt and 1550 rcv) to a product which has 1550 xmt and 1310 rcv, e.g. iMcV-Gigabit, TX/SSLX-SM1550-SC. The two connected products must also have the same speed and distance capabilities (i.e. both are single-mode [20km] or both are single/PLUS [40km]).

DIP Switch Configuration SFP and 1x9

PoE+ Giga-MiniMc SFP



DIP Switch	Name	Definition	Default Setting
1	PoE Reset 2	ON forces Port 2 PoE OFF on LOS of Fiber input	OFF
2	PoE Reset 1	ON forces Port 1 PoE OFF on LOS of Fiber input	OFF
3	LoSpd	ON sets SFP for low speed operation	OFF
4	Factory Set	Do not change	OFF
5	Factory Set	Do not change	OFF
6	Factory Set	Do not change	OFF

LoSPd DSW for PoE+ Giga-MiniMc

The DIP Switch for LoSPd is to allow the end user to set a speed for a fiber SFP under the following conditions:

- Setting the LoSPd DSW to ON will force the SFP to operate at 100Mbps. When set in the default of OFF, the SFP will run at its maximum rate of the SFP installed.
- If a dual speed fiber SFP 100/1000Mbps is installed, setting the LoSpd to ON will force the SFP to operate at 100Mbps


NOTE

Under no conditions will the LoSPd DSW impact any copper SFPs. Some 1000Mbps SFPs may not function properly when forced to 100Mbps.

PoE Reset 1 and PoE Reset 2 DSW

When set to ON, it will force the PSE output power on the copper port OFF when the LINK state is lost on the fiber segment. By default, the DSW is set to OFF.

PoE+ Giga-MiniMc 1x9



DIP Switch	Name	Description	Default Setting
1	PoE Reset 2	ON forces Port 2 PoE OFF on LOS of Fiber input	OFF
2	PoE Reset 1	ON forces Port 1 PoE OFF on LOS of Fiber input	OFF
3	Factory Set	Do not change	OFF
4	Factory Set	Do not change	OFF
5	Factory Set	Do not change	OFF
6	Factory Set	Do not change	OFF


PoE Reset 1 and PoE Reset 2 DSW

When set to ON, it will force the PSE output power on the copper port OFF when the LINK state is lost on the fiber segment. By default, the DSW is set to OFF.

LED Operation SFP and 1x9

The PoE+ Giga-MiniMc includes LEDs for three ports, as shown below:

PoE+ Giga-MiniMc SFP




SFP LED Functions are as follows:

FLT	Glows red when a fault has been detected on the unit
LNK	Glows green with a valid link
1000 Mbps	Glows green when SFP is running at 1000Mbps
PWR	Glows green when unit is powered

RJ-45 LED Functions are as follows:

LNK/ACT	Glows green with a valid link Blinks green when activity is detected
PSE	Glows green when port is supplying PoE power Blinks green during training and fault conditions: a series of two flashes indicates an overcurrent fault; a series of five flashes indicates invalid low or high discovery signature resistance. Off if the port is not supplying power

PoE+ Giga-MiniMc 1x9



1x9 LED Functions are as follows:

FLT	Glows red when a fault has been detected on the unit
LNK	Glows green with a valid link
1000 Mbps	Glows green to indicate is running at 1000Mbps
PWR	Glows green when unit is powered

RJ-45 LED Functions are as follows:

LNK/ACT	Glows green with a valid link Blinks green when activity is detected
PSE	Glows green when port is supplying PoE power Blinks green during training and fault conditions: a series of two flashes indicates an overcurrent fault; a series of five flashes indicates invalid low or high discovery signature resistance. Off if the port is not supplying power

Powering Options


As a standalone unit, the PoE+ Giga-MiniMc uses a universal external desktop switching power adapter. The PoE+ Giga-MiniMc also includes a DC terminal block to support a voltage range of 51 to 57 VDC.

PoE+ Giga-MiniMc supports two powering options.

- Desktop AC power adapter with country specific power cord (included)
- The 4-terminal DC power block

DC Terminal Block Wiring Instructions

The PoE+ Giga-MiniMc can be powered via the DC terminal block. From a power source, connect to any one positive and any one negative terminal on PoE+ Giga-MiniMc.




PoE+ Giga-MiniMc

NOTE

When using stranded wire, the leads must be tinned, and equivalent to a 16 AWG solid conductor. The *PoE+ Giga-MiniMc* is protected against mis-wiring; if mis-wired the *PoE+ Giga-MiniMc* will not function. The *PoE+ Giga-MiniMc* cannot support -48 VDC.

DIN Rail and Wallmount Bracket

The PoE+ Giga-MiniMc can be mounted with two DIN Rail clips, a hardware option available through IMC Networks. The DIN Rail clips include screws, to allow the installation onto a DIN Rail. Install the screws into DIN Rail clips, which should be mounted perpendicular to the DIN Rail. Snap the converter onto the clips. To remove the converter from the DIN Rail, use a flat-head screwdriver into the slot to gently pry the converter from the rail. In addition, a Wallmount bracket can be installed onto the PoE+ Giga-MiniMc (optional purchase).



Wallmount Bracket

Din Rail Mounting

NOTE

The DIN clips are designed for use on a DIN-35 rail.

DC Power Supply Precautions

The following precautions should be observed when installing chassis with DC power supplies.

1. Check nameplate ratings to assure there is no overloading of supply circuits that could have an effect on overcurrent protection and supply wiring.
2. When installing 51 to 57 VDC rated equipment, it must be installed only per the following conditions:
 - a. Connect the equipment to a 51 to 57 VDC supply source that is electrically isolated from the alternating current source. The 51 to 57 VDC source must be connected to a 51 to 57 VDC SELV source.
 - b. The maximum terminal voltage is 57 VDC.
 - c. Input wiring to terminal block must be routed and secured in such a manner that it is protected from damage and stress. Do not route wiring past sharp edges or moving parts.
 - d. A readily accessible disconnect device, with a 3mm minimum contact gap, shall be incorporated in the fixed wiring.
3. Grounding: reliable grounding of this equipment must be maintained. Particular attention should be given to supply connections when connecting to power strips, rather than direct connections to the branch circuit. The Negative Terminal is common to the grounded case.
4. -48 VDC cannot be supported.


Troubleshooting

If the PoE+ Giga-MiniMc is not responding to the power provided to it, the following conditions may be responsible:

- There may be an overcurrent condition; this is indicated on the PSE LED by a series of two flashes.
- There may be an invalid low or high discovery signature resistance; this is indicated on the PSE LED by a series of five flashes.
- If the PoE injector has power that can be verified, but the PSE LED is off, then contact IMC Networks technical support.

RJ-45 Pinouts

The following table lists the pin configuration for the RJ-48 connector.



Pin#	Signal Name 1000M	Signal Direction 10/100M	PoE PoE+ (ALT-B)	Pin#
1	TXD1+	Out*		1
2	TXD1-	Out*		2
3	RXD2+	IN*		3
4	D3+		+V	4
5	D3-		+V	5
6	RXD2-	In*		6
7	D4+		-V	7
8	D4-		-V	8

Specifications for the PoE+ Giga-MiniMc

Multi-mode 1300nm Dual Fiber
Single-mode 1310nm 1550nm Dual Fiber
Single-mode 1310nm 1490nm Single-Strand Fiber
Single-mode 1310nm 1550nm Single-Strand Fiber
Copper 10/100/1000Mbps

Ethernet Connections

10/100/1000 BaseT
Auto Negotiation
AutoCross
Flow Control
10240 MTU
Full Line-Rate Forwarding

DC Input Voltage

51 to 57 VDC on DC terminal block
51 to 57 VDC on DC jack

AC Desktop Adapter

100 to 240 \pm 10% VAC input, 52 VDC output, 2.31A max

Power Consumption

65W max (PSE + PD)
5W max (PSE)

Operating Temperature

+32°F to +143.6°F (0°C to +62°C) DC terminal block
+32°F to +122°F (0°C to +50°C) with IMC supplied AC desktop adapter

Storage Temperature

-40°F to +185°F (-40°C to +85°C)

Humidity

5% to 95% (non-condensing); 0 to 10,000 ft. altitude

Power Characteristics

Consumes less than 10 watts (heating) plus PSE power
IEEE802.3af/at Power to field < 50 watts (2 x 24.5 watts)
Powered from external 51 to 57 VDC power jack
Powered from external 51 to 57 VDC 4-position terminal block
The input power terminals are isolated from the unit chassis
Threaded Chassis Grounding holes on unit for ground lug mounting

Standards Compliance

IEEE 802.3af Power Over Ethernet

IEEE 802.3at PoE+ Standards

IEEE 802.3 Ethernet Standards

IEEE 802.3u Auto-Negotiation

RFC-2474

RFC-2475 DiffServ QoS

IMC Networks Products	Length of Warranty
SFPs	1 year
PoE+ Giga-MiniMc	6 year

NOTE

Please refer to the Warranty Section at the beginning of this manual for the full terms of the warranty.

Notes

PoE Precautions (For Inside-a-Building Installation ONLY)

The PoE Giga-MiniMc and PoE+ Giga-MiniMc are for inside-a-building installation only. Both devices cannot be installed outside-a-building environment, as they cannot meet the PoE requirements, per the PoE standard. If installing the device outside, serious damage can occur and void the IMC Networks' warranty.

IMC Networks Technical Support

Tel: (949) 465-3000 or (800) 624-1070 (in the U.S. and Canada);
+32-16-550880 (Europe)

Fax: (949) 465-3020

E-Mail: techsupport@imcnetworks.com

Web: www.imcnetworks.com

Fiber Optic Cleaning Guidelines

Fiber Optic transmitters and receivers are extremely susceptible to contamination by particles of dirt or dust, which can obstruct the optic path and cause performance degradation. Good system performance requires clean optics and connector ferrules.

1. Use fiber patch cords (or connectors, if you terminate your own fiber) only from a reputable supplier; low-quality components can cause many hard-to-diagnose problems in an installation.
2. Dust caps are installed at IMC Networks to ensure factory-clean optical devices. These protective caps should not be removed until the moment of connecting the fiber cable to the device. Should it be necessary to disconnect the fiber device, reinstall the protective dust caps.
3. Store spare caps in a dust-free environment such as a sealed plastic bag or box so that when reinstalled they do not introduce any contamination to the optics.
4. If you suspect that the optics have been contaminated, alternate between blasting with clean, dry, compressed air and flushing with methanol to remove particles of dirt.

Electrostatic Discharge Precautions

Electrostatic discharge (ESD) can cause damage to any product, add-in modules or stand alone units, containing electronic components. Always observe the following precautions when installing or handling these kinds of products

1. Do not remove unit from its protective packaging until ready to install.
2. Wear an ESD wrist grounding strap before handling any module or component. If the wrist strap is not available, maintain grounded contact with the system unit throughout any procedure requiring ESD protection.
3. Hold the units by the edges; do not touch the electronic components or gold connectors.
4. After removal, always place the boards on a grounded, static-free surface, ESD pad or in a proper ESD bag. Do not slide the modules or stand alone units over any surface.



WARNING! Integrated circuits and fiber optic components are extremely susceptible to electrostatic discharge damage. Do not handle these components directly unless you are a qualified service technician and use tools and techniques that conform to accepted industry practices.

Safety Certifications

UL/CUL: Listed to Safety of Information Technology Equipment, including Electrical Business Equipment.

CE: The products described herein comply with the Council Directive on Electromagnetic Compatibility (2004/108/EC) and the Council Directive on Electrical Equipment Designed for use within Certain Voltage Limits (2006/95/EC). Certified to Safety of Information Technology Equipment, Including Electrical Business Equipment. For further details, contact IMC Networks.



**Class 1 Laser product, Luokan 1 Laserlaite,
Laser Klasse 1. Appareil A'Lasers de Classe 1**

European Directive 2002/96/EC (WEEE) requires that any equipment that bears this symbol on product or packaging must not be disposed of with unsorted municipal waste. This symbol indicates that the equipment should be disposed of separately from regular household waste. It is the consumer's responsibility to dispose of this and all equipment so marked through designated collection facilities appointed by government or local authorities. Following these steps through proper disposal and recycling will help prevent potential negative consequences to the environment and human health. For more detailed information about proper disposal, please contact local authorities, waste disposal services, or the point of purchase for this equipment.





19772 Pauling • Foothill Ranch, CA 92610-2611 USA
TEL: (949) 465-3000 • FAX: (949) 465-3020
www.imcnetworks.com

**ISO 9001:2008
REGISTERED**



© 2011 IMC Networks. All rights reserved.

The information in this document is subject to change without notice. IMC Networks assumes no responsibility for any errors that may appear in this document. PoE Giga-MiniMc and PoE+ Giga-MiniMc is a trademark of IMC Networks. Other brands or product names may be trademarks and are the property of their respective companies.

Document Number 57-80912-00 A0

September 2011